

1983_AURICULARES SHIZAR RCS

FRONT PART

1983 - Auriculares Shizar RCS Manual de instrucciones (Esp)



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

Descripción del Producto:



Especificaciones:

- Versión Bluetooth 5.1
- Distancia de funcionamiento: Hasta 10 metros
- Frecuencia: 20Hz-20KHz
- Auriculares: Batería de Polímero de Litio 30mAh
- Estación de carga: Batería de Polímero de Litio 300mAh
- Voltaje de carga: 5V
- Tiempo de carga: 1-1.5h
- Tiempo en funcionamiento: 4-5h
- SNR: 92dB
- Impedancia: 32ohms
- Distorsión: menos del 6%
- Soporta A2DP, AVCTP, AVDTP, AVRCP, HFP, SPP
- Cable de carga incluido

Carga:

Estación de carga

Utilice para la carga el cable suministrado. Conecte el cable USB a su ordenador/adaptador de corriente alterna y conecte el otro extremo del cable en el puerto de carga del dispositivo. El indicador luminoso de color blanco parpadeará durante el proceso de carga. Una vez finalizado permanecerá fijo.

Nota: Si introduce los auriculares, estos se cargarán de forma simultánea.

Auriculares

Introduzca los mismos en la estación de carga y el proceso se iniciará de manera automática.

Durante el proceso de carga, los indicadores de color blanco permanecerán encendidos. Una vez se hayan cargado completamente, los mismos se apagarán.

Funcionamiento:

Puede hacer uso de uno o ambos auriculares al mismo tiempo. Al extraer los auriculares de la estación de carga se sincronizarán de forma automática.

Si se encuentran apagados y fuera de la estación de carga, mantenga pulsado el botón multifunción de ambos auriculares durante unos 3 segundos, y un indicador luminoso de color blanco comenzará a parpadear. Esto indica que el dispositivo está listo para ser emparejado.

Desde el menú Bluetooth de su dispositivo móvil, busque nuevos dispositivos y seleccione "1983" para asociarlo a su teléfono. Una vez asociados el indicador luminoso se apagará.

Mantenga pulsado el botón multifunción de cada auricular para apagarlos.

Controles:

Responder/Colgar una llamada:

Pulse una vez el botón multifunción de cualquier auricular.

Rechazar una llamada:

Mantenga pulsado el botón multifunción de cualquier auricular para rechazar una llamada entrante.

Reproducir/Pausar la música: Pulse una vez el botón multifunción de cualquier auricular.

Cambio de pista:

Para pasar a la siguiente canción, pulse el botón multifunción del auricular derecho durante dos veces. Para retroceder a la pista anterior, realice la misma acción en el auricular izquierdo.

Volumen:

Para incrementar el volumen, pulse el botón multifunción del auricular derecho tres veces. Para retroceder a la pista anterior, realice la misma acción en el auricular izquierdo.

Solución de problemas

Fallo	Solución
Imposible conectarse a otros dispositivos.	1. Revise si el auricular sigue en el proceso de búsqueda. Apáguelo y enciéndalo nuevamente. 2. Hay demasiados dispositivos Bluetooth alrededor que causan dificultad en la conexión. Por favor desconéctelos. 3. Asegúrese de que está en "modo asociación"
El sonido es bajo o distorsionado.	4. Revise el volumen de su dispositivo y ajústelo a un nivel adecuado. 5. Recargar la batería.
La música se detiene de vez en cuando.	6. Revise si la distancia efectiva de transmisión del auricular es excesiva o si existe algún obstáculo entre el auricular y el dispositivo Bluetooth.

Advertencias:

1. No lo exponga a la lluvia o entornos mojados.
2. Evite caídas que le puedan generar daños serios.
3. No intente reparar la unidad por sí mismo, contacte con un especialista.
4. Para evitar riesgos, no se deshaga de él de manera inapropiada ya que posee una batería de litio integrada.
5. Límpielo con un trapo seco.
6. No lo instale cerca de fuentes de calor.
7. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito.
8. El uso de auriculares a un volumen excesivo puede causar pérdidas de audición.
9. Mantenga fuera del alcance de los niños.



MADE IN PRC



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local.

Por la presente, Mtko Catal Importaciones S.L. declara que este equipo radioeléctrico es conforme con la Directiva 2014/53/EU. El texto completo de la declaración UE de conformidad está disponible en: www.mtko.es (busque por referencia).

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. De Huerca-Overa, s/n, 04640, Pulpí, Almería, Spain.

BACK PART

1983 - Earphones Shizar RCS User manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Specifications:

- Bluetooth Version 5.1
- Operating distance: Up to 10 meters
- Frequency: 20Hz-20KHz
- Earphones: Lithium polymer battery 30mAh
- Charging station: Lithium polymer battery 300mAh
- Charging voltage: 5V
- Charging time: 1-1.5h
- Working Time: 4-5h
- SNR: 92dB
- Impedance: 32ohms
- Distortion: less than 6%
- Compatible with A2DP, AVCTP, AVDTP, AVRCP, HFP, SPP
- Charging cable included

Charging:

Charging station

Use the cable provided for charging. Connect USB cable to computer / AC adapter and connect the other end of the cable into the charging port of the charging station. During the charging process, the led indicator will blink in white colour. Once finished, led indicator will stay on.

Note: If the earphones are in the charging station, both will be charged at the same time.

Earphones

Place the earphones into the charging station and the charging process will start automatically.

During charging the white light will stay on. When the earphones are fully charged the indicator light will turn off.

Operation:

You can use one or both earphones at the same time.

When you remove the earbuds from the charging station they will synchronize automatically.

If they are turned off, press and hold the multifunction button to power on the earphone until the indicator light start flashing in white colour. This indicates that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "1983" to pair. Once they are paired successfully, the light indicator will turn off in one of the earphones.

Press and hold the multifunction button of each earphone to power off the device.

Controls:

Answer/End call:

Short press the multifunction button of any earphone.

Reject call:

Long press the multifunction button of any earphone.

Play/Pause music:

Short press the multifunction button of any earphone.

Next/previous Track:

To go to next track, press two times the multifunction button on the right earphone. To go to previous track, proceed in same way on the left earphone

Volume:

To increase the volume level, press three times the multifunction button on the right earphone. To decrease the volume level, proceed in same way on the left earphone

Troubleshooting

Fault	Solution
Unable to pair up with other devices.	1. Check whether the earphone is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your earphone is in "Pairing Mode".
The sound is low or distorted.	4. Check the Bluetooth device's volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the earphone effective transmission range is exceeded or if there is an obstacle standing between the earphone and other Bluetooth devices.

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Excessive sound pressure from earphones and headphones can cause hearing loss.
9. Keep out of reach of children.



MADE IN PRC



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Hereby, Mtko Catal Importaciones S.L. declares that this radio equipment is in compliance with Directive 2014/53/EU. The full text of the UE declaration of conformity is available at: www.mtko.es (search on reference).

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. De Huerca-Overa, s/n, 04640, Pulpí, Almería, Spain.